

## **FSS-18 INSTALLATION SPECIFICATIONS**

## **ERECTION NOTES:**

1. Inspect factory applied caulking on the female leg of FSS-18 roof panels. Field apply a 3/16" x 3/16" bead of caulking to the underside of the female leg where caulking is missing or disturbed. Field apply a 3/16" x 3/16" bead of caulking over and under female leg of fixed clips or expansion clips. A tube of caulking (11 Fluid OZ.) will yield approximately an 3/16" x 3/16" x 42 lineal feet bead (This is allowing for a 10 % waste factor).

- 2. Attach fixed clips to framing using (2) #12/14 x 1 1/2" H.H. SDMS.
- 3. Hand crimp panels @ fixed clip locations, penetrations, and 2'-0" @ eaves & ridge.

4. 1/8" x 1 5/8" sealer tape to be field applied continuously under plug closures and roof panels at the eave line. See details

- and sections for proper placement of sealer tape.
- 5. Three rows of caulking (1/8" x 1/8" Beads) to be field applied between vertical legs of roof panels @ eave line (See Details).
- 6. Roof panels are to be square with building & aligned using marks @ the eaves & ridge. Marks maintain 18" width of panel through out on center. A string line should be used to maintain a straight eave line.
- 7. Vertical legs of roof panels to be held tightly together at the eave and clip locations by using clamps.
- 8. Closures to be field installed between gable trim and endwall panels.
- 9. Any cutting of panels @ openings or end of runs is to be done by the erector in the field.
- 10. Remove all strippable plastic as panels & flashings are being erected.
- 11. Any metal shavings from field cutting or drilling, must be cleaned off roof or siding daily to prevent rust and/or discoloration of panels.
- 12. Installation should be done by people skilled in this trade, using proper saftey procedures.
- 13. Self driller screws are shown, A-PNT, B-PNT, Woodtites, etc. Screws can be substituted at customer's request.
- 14. If you are matching existing trim, provide drawings and dimensions for each.
- 15. Fixed clips can be substituted for expansion clips under 40" panel lengths.
- \*16. Customer to provide drawings and dimensions.

## **GENERAL NOTES:**

1. Cut charges apply to panels over 40'-0" lg. and to panels under 6'-0" lg.

2. Due to the individualized nature of projects, the customer is responsible for the correct panel lengths and quantities, and all accessory sizes, types and quantities.

3. When unloading panels, a spreader bar and nylon straps of the proper size, length and spacing should be used by skilled personnel to prevent buckling of the panels or bodily injury.

4. Moisture on the inside of the stacked panels can be very harmful to the panels in a short period of time. Inspect the panels immediately upon arrival for any moisture that may have formed during shipment and if any moisture is present, the panels must be unpackaged, wiped dry and restacked.

5. Inside storage is preferable, but if not possible, the panels should be stored at least one foot above ground, with one end elevated, and covered loosely to allow air to circulate.







INCORRECT