FE 12 CONCEALED FASTENER PANEL INSTALLATION SPECIFICATIONS

ERECTION NOTES:

- 1. FE 12 panels are siding panels only and are not to be used for roofing applications.
- 2. FE 12 panels to be supplied with vinyl panel spline (Gasket) that is to be field applied to the male leg of all panels during installation.
- 3. Square and align FE 12 with building using marks @ the eaves and base. Marks are12" on center.
- 4. Field cut or bevel panels @ ends of panel runs or penetrations.
- 5. Remove all strippable plastic as panels are being erected.
- 6. Remove any metal shavings from field cutting or drilling daily to prevent rust and/or discoloration of panels.
- 7. Skilled tradespeople should complete installation of FE 12 panels, using proper saftey procedures.
- 8. Self driller screws are shown, A-PNT, B-PNT, Woodtites, etc. Screws can be substituted at customer's request.
- 9. If you are matching existing trim, provide drawings and dimensions for each.
- 10. 18 and 20 gauge flashings are not made w/ hems.

*11. Customer to provide drawings and dimensions.

GENERAL NOTES:

1. Cut charges apply to panels over 40'-0" lg. and to panels under 6'-0" lg.

2. Due to the individualized nature of projects, the customer is responsible for the correct panel lengths and quantities, and all accessory sizes, types and quantities.

3. When unloading panels, a spreader bar and nylon straps of the proper size, length and spacing should be used by skilled personnel to prevent buckling of the panels or bodily injury.

4. Moisture on the inside of the stacked panels can be very harmful to the panels in a short period of time. Inspect the panels immediately upon arrival for any moisture that may have formed during shipment and if any moisture is present, the panels must be unpackaged, wiped dry and restacked.

5. Inside storage is preferable, but if not possible, the panels should be stored at least one foot above ground, with one end elevated, and covered loosely to allow air to circulate.



